

**PERMATRON<sup>®</sup>**

# ADJUSTABLE AIR FILTER

Fits all sizes  
14"x14" to 20"x25"

**The permanent washable air filter.**

- Permanent - Never Needs Replacing •
- Much More Effective Than Ordinary, Throw-Away Filters •
- Anti-Bacterial Agent Manufactured Into The Filter Media •
- Lifetime Warranty •
- Independent Laboratory Tested •

## **EFFECTIVE**

Initial resistance to airflow 0.12;  
peak arrestance efficiency up to 83%

## **WASHABLE/REUSABLE**


Simply rinse every 30 days

## **EASY INSTALLATION**

No screws needed

## **ANTI-BACTERIAL**

Anti-Microbial Treatment inhibits  
growth of bacteria on filter surface



Helps remove the above Allergen Particles

## Adjustable Air Filter Installation

**Tools Needed: Scissors, Tape Measure**

1. Using a tape measure or ruler, measure the length and width of the filter you are replacing.
2. Before disassembling the four pieces of the framing system, note how the frame pieces slide together.
3. Separate the filter grids and foam pad.
4. Trim the desired size  $\frac{1}{4}$ " shorter in each direction to allow for the width of the frame. If the desired size is  $13 \frac{3}{4}$ " by  $17 \frac{3}{4}$ ", trim the components to  $13 \frac{1}{2}$ " by  $17 \frac{1}{2}$ ".
5. Cut along just two sides of the Adjustable filter to fit any size frame. Suggestion: Cut the first component to desired dimension. Use this piece as a guide for the two other components, insuring equal dimensions for all three components.
6. Insert the filter material into the frame channels and slide the frame sections together so the components are securely in place. Easier assembly can be accomplished by working on a flat surface.
7. Your filter is now ready for installation. Important: To maintain the highest possible efficiency, make sure the filter is sized properly for a secure fit. Filter should fit snugly into the return air grate. Air moving around the filter will decrease the filter performance. For best filter performance, run household recirculating fan.



**Maintenance:** About every 30 days, remove the filter and rinse it until water runs clear. Use a mild detergent or filter cleaner to remove any grease or tobacco build up. Lightly shake off excess water and return filter to system. Air flow will completely dry the filter.

### LIFETIME WARRANTY

Permatron takes pride in the quality and workmanship of our products. All are built to give years of trouble-free service. Any filter found to be defective in workmanship or materials, when returned to Permatron shipping charges prepaid, will be repaired or replaced without charge. The warranty period begins from the date of purchase and does not cover damage caused by excessive heat, rough handling or improper installation. Once assembled, it is not necessary to take the unit apart for cleaning. With proper care and regular cleaning, your Permatron filter should last many years. Permatron Corporation make no medical or health claims other than that the filter will effectively remove particles from the air.